Getting Started with the Lightcloud Installation App

LC Installer

Overview Features Installation Step



RAB[®] Controls

Overview

Use the Installer App to scan and organize Lightcloud Devices. The Device information is then seamlessly sent to RAB for free, remote commissioning. It's really that simple.

Features

- Multi-Site
- Multi-Gateway
- Assign Devices to Rooms
- Assign Device Zone Names
- Assign Dimmers to Controllers
- Create Installation Notes

The Installer App is for setting up/commissioning a Lightcloud system. For lighting controls and management, please use the Lightcloud App.

Questions?

1 (844) - LIGHTCLOUD

Available on the iPhone App Store



Follow these easy steps to install your Lightcloud site.

1. Position the Gateway

The Gateway should be located centrally to as many Lightcloud devices as possible and have a strong cellular signal.

Test the Gateway Signal Strength—must be green before installation.



Install one Gateway and related devices at a time.

2. Scan the Gateway's Device ID

The Device ID is used to identify each device in the system.



3. Permanent Power to the Gateway

Wire the Gateway for permanent, unswitched power.



Don't use a plug-in power cord for permanent installation.

4. Position Devices

Lightcloud devices send, receive, and repeat wireless signals. Each device needs to be within range of at least one other device and have a pathway back to the Gateway.



4. Position Devices Continued Indoor Range: 100 feet through standard building materials such as drywall.

Outdoor Range: 1000 feet without any obstructions.

Use the chart below to see affects of various building materials.



5. Scan Device Scan Device ID and verify that the number scanned correctly.



Device IDs

6. Complete Device Information Be as detailed as possible.

	Contro	ller	
1	Device ID	0013A20040F6293F	r.
	Location	Lobby	ľ
	Zone Name	3 EZPAN Row South	
K	Dimmable		
	Power Monitoring		
	Panel/ Circuit #	LP 2	
	Cancel	Save	
The contraction of the second	- KI		

7. Install Devices

Wire for permanent, unswitched power.



BREAKER BOX OR CONSTANT POWER SOURCE

8. Test Devices

Ensure the status indicator is solid Green and test dimming and switching using the device identification button.



9. Send to RAB

After scanning and installing all of the devices, submit the information by pressing 'Send to RAB'.



More Info View the Planning Guidelines Visit lightcloud.com/resources

Questions?

Free Support — Call 1(844)LIGHTCLOUD

Interested?

lightcloud.com

1 (844) LIGHTCLOUD



©2018 RAB Lighting, Inc. RAB is continually improving our products. Specifications may change without notice. The designs of RAB fixtures are protected under U.S. and international intellectual property laws.